



CQ EMC version for electromagnetic compatibility

inserts		page:
CQ 04/2	4 poles + 2 poles + ⊕	191
CQ 08	8 poles + ⊕	192
CQ 17	17 poles + ⊕	193

bulkhead mounting housings
with single lever



angled bulkhead mounting housings
with single lever




metallized insulating enclosures


description	part No.	entry Pg
with lever and gasket	CQS 08 I	
without cable gland, with lever, angled		CQS 08 IA
with cable entry, with lever, angled		CQS 08 IAP 21

ASSEMBLY INSTRUCTIONS


When using an EMC “CQS 08” series enclosure with a male insert, replace the standard gasket provided on the male insert with a conductive gasket CR 08 EMC, to be ordered separately (see page 575).




CQS I




panel cut-out for CQ I enclosure




CQS IA



CQS IAP



panel cut-out for CQ IA - CQ IAP enclosure



CU[®]US Type 12

