FEDERAL SIGNAL

Radiant Stack Light

Configurable to fit every need



Single Color Configurations

The Radiant modular stack light allows for up to 7 light modules; 6 light modules and 1 sound module (1 channel/tone); or 5 light modules and 1 sound module (2 channels/tones).

Multicolor Configurations

The Radiant module stack light allows for up to 2 RGB multicolor LED modules and 1 sound module (1 channel) or 1 RGB multi-color LED module, 2 fixed color LED modules and 1 sound module (2 channels).


How to Configure Your Stack Light

Follow the ○ to configure a ***steady*** stack light.

Follow the □ to configure a ***flashing*** stack light with flashing controls in the light module. **This allows the user to select a different flash pattern for each light module.**


Follow the △ to configure a ***flashing and steady*** stack light with flashing controls in the wiring module.**This option requires all light modules to have the same flash pattern.**

Follow the ◇ to configure a ***multipattern and multicolor*** stack light with flashing controls in either the wiring module or the light module.






TOP CAP
Included with wiring and sound module



RSL-SM
Piezoelectric sound module (2 tones) includes attached top cap



RSL-SMM
Piezoelectric sound module (16 tones) includes attached top cap



RSL-LMS
LED light module



RSL-LMB
Bright LED light module



RSL-LMM
Multi-pattern superbright LED light module (4 light effects)



RSL-LM-RGB
Multicolor and Multi-Pattern LED Light Module



RSL-WML
Wiring module 12-24VAC/DC




RSL-WMLM
Multi-pattern wiring module 12-24VAC/DC (4 light effects)




RSL-WMH
Wiring module 120-240VAC



RSL-WMHM
Multi-pattern wiring module 120-240VAC (4 light effects)




RSL-BF
Flat Base




RSL-BW
Wall Base



RSL-BP
Pipe Mount



RSL-BE
Extended Base



RSL-BT
Tube Base (4 lengths)

For additional configuration information, reference "How to Order" section on individual product pages.
Note: top cap provided with each wiring module.

2645 Federal Signal Dr., University Park, IL 60484 Tel: +1 708.534.4756 Email: signalsupport@fedsig.com www.fedsig.com