

Serial Communication Cable (MA001)

The Panduit G5 iPDU provides a Command Line Interface (CLI) that enables data center administrators to perform basic management tasks. The Serial Communication Cable (RJ45-DB9) is used to establish a serial connection between a computer and a Panduit G5 iPDU.



Serial Communication
Cable

INSTALLATION INSTRUCTIONS

1. Insert the RJ45 end of the Serial Communication Cable into the “PDU In/Serial” port on the Panduit G5 iPDU.
2. Insert the DB9 end of the cable into the serial (COM) port on a computer.
Note: A serial-to-USB converter may be required if the computer does not have a DB9 serial port.
3. Use the connected computer to open a communications program such as HyperTerminal or PuTTY.
4. Select the appropriate COM port and ensure the port settings are as follows:
 - Bits per second: 115200
 - Data bits: 8
 - Stop bits: 1
 - Parity: None
 - Flow control: None

The Panduit iPDU is connected and ready for communication.